

Quick Start >>



Cloud Camera

See more · Be sure

Power on the camera.



System LED



Flashing red: Wi-Fi not connected

Flashing green: Wi-Fi connected (local view only)

- I Solid green: Wi-Fi connected (local&remote view)
- I Solid red: System restarting



Smartphone requirements: Android 4.1 or higher iOS 7.0 or higher Download and install the **tpCamera** app in your smartphone.

2



OR







3

Launch tpCamera, log into your TP-LINK Cloud account or create one, then follow the app instructions to set up your new camera.








Unscrew the camera head.



```
Remove the base cover.
```



Use two screws to secure the base.



Put the base cover and camera head back on.

about TP-LINK Cloud Camera.

7106506025 REV1.0.0 ©2016 TP-LINK

Via Smartphone:

On the **My Cam** screen, tap your camera to view the live video.



Via Computer:


Log into the TP-LINK Cloud website (https://www.tplinkcloud.com), and click your camera to view the live video.



How to use the RESET Button

① Note

Resetting a registered camera will remove it from your TP-LINK Cloud account.



While the camera is powered on, press the **RESET** button for **5** seconds until the System LED on the front panel turns solid red. The camera will reset and reboot.

Get more with the camera

Get notifications when motion is detected

Tap $\frac{\pi}{2}$ from **My Cam** screen to set Motion Detection in your tpCamera app.

View all of your cameras on one screen

Download and install the TP-LINK Camera Control utility to view and manage multiple cameras on one screen. For details, see the Camera Control User Guide.

Downloads

For related user guides, Camera Control utility, camera firmware, and other supports, please visit the product page at http://www.tp-link.com.





Use only power supplies which are provided by manufacturer and in the original packing of this product. If you have any questions, please don't hesitate to contact us.

EAC